

■ 1. Dishwasher – Mini Guide

■ How to turn it on

1. Open the dishwasher.
2. Press the POWER/ON button.
3. Select the washing program (usually Eco or Quick 45').
4. Press START.

■ How to use it

- Quickly rinse dishes before loading them.
- Load plates and glasses without overlapping.
- Add the dishwasher tablet into the detergent compartment.
- Close the door: the cycle starts automatically.

■ What NOT to do

- Do not use regular dish soap → it creates foam and damages the machine.
- Do not insert wooden items, premium knives, or aluminum objects.
- Do not block the rotating spray arms: the wash cycle will not work.



❄️ ■ 2. Air Conditioner – Mini Guide

■ How to turn it on

1. Use the remote control.
2. Press ON.
3. Select the mode:
 - ❄️ ■ COOL (cold)
 - ■ HEAT (warm)
 - ■ ■ FAN (ventilation)
4. Set the ideal temperature: 24–26° in summer, 20–22° in winter.

■ How to use it

- For fast cooling, use COOL mode with medium fan speed.
- Keep windows and doors closed.
- Point the air flaps upwards for cold or downwards for heat.

■ What NOT to do

- Do not go below 22°: it wastes energy and may cause condensation.
- Do not use the unit with open windows.
- Do not cover or obstruct the indoor unit.



■ 3. Toaster – Mini Guide

■ How to turn it on

1. Plug it in.
2. Insert the bread into the slots.
3. Adjust the browning level (1–6).

4. Push the lever down.

■ How to use it

- The bread pops up automatically when ready.
- To stop early, press STOP/CANCEL.

■ What NOT to do

- Do not insert wet or filled foods.
- Do not attempt to remove bread with forks or metal objects.
- Do not leave the toaster unattended while operating.



■ 4. Electric Kettle – Mini Guide

■ How to turn it on

1. Fill the kettle with water (up to the MAX level mark).
2. Place it onto the base.
3. Press ON.

■ How to use it

- It switches off automatically when the water boils.
- Fill with water only (no milk, tea, etc.).

■ What NOT to do

- Do not touch the kettle while hot.
- Do not fill above the MAX level.
- Never insert liquids other than water.



■ 5. Induction Cooktop – Mini Guide

■ How to turn it on

1. Place the pot on the induction zone.
2. Press the ON/OFF button.
3. Select the cooking zone.
4. Set the power level (+ / –).

■ How to use it

- Use only induction■compatible cookware.
- The zone heats only when a pot is placed on it.
- Boiling: level 8–9.
- Cooking: level 4–6.
- Keep■warm: level 1–2.

■ What NOT to do

- Do not place empty cookware on a powered zone.
- Do not use warped or damaged pans.

- Do not clean the cooktop while it is switched on.



■ 6. Microwave – Mini Guide

■ How to turn it on

1. Place food in a microwave■safe container.
2. Close the door properly.
3. Set the timer with the + / – buttons.
4. Press START.

■ How to use it

- To reheat: 30 seconds → check → add more time if needed.
- To defrost: use the DEFROST function.
- Always use containers without metal or silver decorations.

■ What NOT to do

- Do not place metal or aluminum foil inside.
- Do not run the microwave empty.
- Do not heat whole eggs (risk of explosion).



■ 7. Hair Dryer – Mini Guide

■ How to turn it on

1. Plug it in.
2. Press the ON switch.
3. Adjust speed and temperature.

■ How to use it

- Use medium power for normal drying.
- For extra volume, use the cool■air function at the end.
- Keep a safe distance from hair and skin.

■ What NOT to do

- Do not use near water (sink, shower, etc.).
- Do not cover the rear air grille.
- Do not leave the hair dryer on unattended.



■ 8. Espresso Coffee Machine (Ground Coffee) – Mini Guide

■ How to turn it on

1. Fill the water tank (use still water only).
2. Switch the machine on by pressing the ON button.
3. Wait until the temperature light turns solid green: the machine is ready to brew.



■ How to use it (step by step)

1. Remove the portafilter (the handle).
2. Fill the filter with ground coffee:
 - Use the measuring scoop (normally 1 scoop = 1 espresso).
 - For 2 coffees use the double filter.
3. Level and gently press the coffee.
 - It should be evenly distributed and only lightly tamped.
4. Reinsert the portafilter and turn to lock it in place.
5. Place the cup under the spouts.
6. Press the brew button.
7. When you reach the desired quantity, press STOP.



■ What NOT to do

- ■ Do not overfill the filter: this creates excessive pressure.
- ■ Do not tamp too hard: water will not pass through.
- ■ Do not leave old coffee in the portafilter.
- ■ Do not use extra-fine (Turkish) grind: it clogs the machine.
- ■ Do not operate the machine without water in the tank.



■ Pro Tip

- If coffee flows too fast, you used too little coffee or tamped too lightly.
- If it drips too slowly, you tamped too hard or the grind is too fine.
- Perfect crema = correct dose + even tamping.

■ 9. Smart TV – Mini Guide

■ How to turn it on

1. Press the POWER button on the remote control.
2. Wait a few seconds for the system to load.



■ How to use it

■ To watch regular TV channels

1. Press the TV or DTV button (depending on the model).
2. Change channels using CH + / CH –.
3. Adjust the volume with VOL + / –.

■ To use apps (Netflix, YouTube, Prime Video, etc.)

1. Press the HOME button (house icon).
2. Select the desired app with the arrows.
3. Press OK to open.

■ If login is required, guests may log in with their own account and should remember to log out when finished.

■ To change input source (HDMI, Fire Stick, etc.)

1. Press SOURCE or INPUT.
2. Select the corresponding port (e.g., HDMI1).
3. Press OK.

■

■ What NOT to do

- ■ Do not change advanced settings (hotel mode, network, factory reset).
- ■ Do not unplug HDMI or power cables.
- ■ Do not perform software updates unless necessary.
- ■ Do not change the language settings unnecessarily.

■

■ Quick Tip

If something does not work:

1. Turn off the TV.
2. Wait 10 seconds.
3. Turn it back on → this often solves the issue.

■ 10. Washing Machine – Mini Guide

■ How to turn it on

1. Load the laundry (do not overfill).
2. Add detergent into the drawer (I = prewash, II = wash, flower = softener).
3. Close the door.
4. Press ON/OFF.
5. Select a simple program:
 - Cotton 40° (standard)
 - Quick 15/30 min (small loads)
 - Synthetics 30°

■ How to use it

- Set the spin speed (800–1000 rpm is ideal for most loads).
- Press START.
- At the end of the cycle, the door unlocks automatically.

■ What NOT to do

- ■ Do not wash shoes, rugs, or extremely heavy items.
- ■ Do not open the detergent drawer during washing.
- ■ Do not force the door if it is locked.
- ■ Do not use too much detergent → it creates foam and may block the cycle.

■

■ 11. Dryer – Mini Guide

■ How to turn it on

1. Insert well■spun laundry (not dripping wet).
2. Close the door.
3. Press ON/OFF.
4. Select a program:
 - Cotton Extra Dry (fully dry)
 - Mix / Synthetics
 - Easy Iron (reduced creases)

■ How to use it

- Press START.
- At the end of the cycle, empty:
- The water tank (if not connected to a drain).
- The lint filter (very important for safety and efficiency).

■ What NOT to do

- ■ Do not dry large duvets or very thick blankets.
- ■ Do not insert plastic, rubber, or delicate metal parts.
- ■ Do not operate with a dirty filter: the dryer may overheat or stop.

■

■ 12. Iron – Mini Guide

■ How to turn it on

1. Fill the tank with tap water up to the MAX level (only if steam function is available).
2. Plug the iron in.
3. Set the temperature according to the fabric type:
 - ● Nylon / delicate fabrics
 - ●● Light cotton
 - ●●● Linen / heavy fabrics
4. Wait until the indicator light switches off = ready to use.

■ How to use it

- Iron gently with smooth continuous movements.
- For steam, press the “steam” button.
- Always use an ironing board for safety.

■ What NOT to do

- ■ Do not leave the iron resting on clothes.
- ■ Do not place the hot iron on delicate surfaces.
- ■ Do not use near water.
- ■ Do not pull the cable or let the iron fall.

■

1■■■ Preparation

1. Fill the water tank

- Remove the rear water tank
- Fill it with cold water
- Reinsert it firmly

2. Switch on the machine

- Press the ON button
- Wait until the “OK” light turns on (this means the temperature is ready)



2■■■ Prepare the portafilter (the handle shown in the photo)

1. Insert the correct filter:

- 1 cup → small filter
- 2 cups → large filter
- ESE pod → pod filter (if supplied)

2. Add ground coffee

- Recommended dose:
- Around 7–8 g per cup
- Level and lightly tamp

3. Attach the portafilter

- Insert it into the brew head under the spout
- Turn to the right until fully locked

4. Place the cup underneath



3■■■ Brew the coffee

1. Press the brew button

2. Allow the coffee to flow

- Ideal extraction time: 20–30 seconds

3. Press again to stop brewing



4■■■ Frothing milk (for cappuccino)

1. Press the steam button

2. Wait until the “OK” light turns on again

3. Insert the steam wand into the milk

4. Open the steam knob

5. Gently move the cup

6. Close the steam knob and clean the wand



5 ■ After use

- Empty the filter
- Rinse it
- Allow it to dry



Useful Tips

- ✓ Use espresso ■ ground coffee
- ✓ Do not overfill the filter basket
- ✓ Tamp lightly and evenly
- ✓ A pre ■ heated cup improves the result
- ✓ Empty the drip tray regularly